Inertial Sensing & Navigation

3/15/2017

GPS Noise




FIGURE 1 GNSS-only results in downtown Calgary

Source: www.insidegnss.com
INS Face Off: MEMS versus FOGs


Using INS to Avoid Noise



FIGURE 3 Integrated MEMS/GNSS trajectory in downtown Calgary

Source: www.insidegnss.com
INS Face Off: MEMS versus FOGs


Offroad INS-only Navigation



Source: www.insidegnss.com
INS Face Off: MEMS versus FOGs

INS Accuracy





Source: Wikipedia

MEMS Accelerometer




Figure 1.2 Illustration of the basic structure of the ADXL family of surface micromachined accelerometers

Source: Design and Analysis of a **MEMS Comb Vibratory Gyroscope**, Haifeng Dong MS Thesis

Tuning-fork Gyroscope




Figure 2.5 Tuning fork structure for angular-rate sensing

Source: Design and Analysis of a MEMS Comb Vibratory Gyroscope, Haifeng Dong MS Thesis

MEMS Gyroscope





Figure 2.9 Angular-rate sensor from Daimler Benz

Source: Design and Analysis of a MEMS Comb Vibratory Gyroscope, Haifeng Dong MS Thesis


Two-dimensional navigation for strapdown system



Source: Basic Principles of Inertial Navigation

Seminar on inertial navigation systems Tampere University of Technology

Two-dimensional navigation for strapdown system



Source: Basic Principles of Inertial Navigation

Seminar on inertial navigation systems Tampere University of Technology

$$\begin{bmatrix} a_N \\ a_E \end{bmatrix} = \begin{bmatrix} cos\psi & -sin\psi \\ sin\psi & cos\psi \end{bmatrix} \begin{bmatrix} a_X \\ a_Y \end{bmatrix}$$

Equations for 2D Strap-Down INS

$$\begin{bmatrix} a_N \\ a_E \end{bmatrix} = \begin{bmatrix} cos\psi & -sin\psi \\ sin\psi & cos\psi \end{bmatrix} \begin{bmatrix} a_X \\ a_Y \end{bmatrix}$$

$$\begin{split} V_N(t) &= V_N(t_0) + \int_{t_0}^t a_N(t) dt & X_N(t) = X_N(t_0) + \int_{t_0}^t V_N(t) dt \\ V_E(t) &= V_E(t_0) + \int_{t_0}^t a_E(t) dt & X_E(t) = X_E(t_0) + \int_{t_0}^t V_E(t) dt \end{split}$$

Gimbaled INS example




Source: Basic Principles of Inertial Navigation Seminar on inertial navigation systems Tampere University of Technology

RLG instrument cluster (Marconi FIN3110 strapdown INS)




Source: Basic Principles of Inertial Navigation Seminar on inertial navigation systems Tampere University of Technology

Strapdown inertial navigation unit block diagram



Source: Basic Principles of Inertial Navigation Seminar on inertial navigation systems


Tampere University of Technology



External frame of reference

Kid's frame of reference

Coriolis Effect



Source: wikipedia

https://www.youtube.com/watch?v=dt_XJp77-mk

Sources of Noise

Error Type	Description	Result of Integration
Bias	A constant bias ϵ	A steadily growing angular error
		$ heta(t) = \epsilon \cdot t$
White Noise	White noise with some standard deviation σ	An angle random walk, whose standard deviation
		$\sigma_{ heta}(t) = \sigma \cdot \sqrt{\delta t \cdot t}$
		grows with the square root of time
Temperature	Temperature dependent residual	Any residual bias is integrated into the orienta-
Effects	bias	tion, causing an orientation error which grows lin-
		early with time
Calibration	Deterministic errors in scale fac-	Orientation drift proportional to the rate and du-
	tors, alignments and gyro linear-	ration of motion
	ities	
Bias Insta-	Bias fluctuations, usually mod-	A second-order random walk
bility	elled as a bias random walk	

Table 2: A Summary of Gyro Error Sources.

Source: An introduction to inertial navigation, Oliver J. Woodman, UCAM-CL-TR-696